



Tel: 0086-025-58196288


Fax:0086-025-58196399

Website: www.msbox.com

E-mail:onlysariel@gmail.com

Floor 22, Huaqiao Square, Pukou district, Nanjing,China

MS EXPANSION JOINT FIRE BARRIER SPEC DATA



INSTALLATION

- Remove and repair all unsound concrete in and around the joint. opening. All spalls must be repaired with compatible patching material.
- Uncoil fire barrier and fold into a “U” shape configuration.
- Install fire barrier into expansion joint opening.
- Attach expansion joint system per Installation Guideline.
- Install anchors at specified intervals.

SELECTION GUIDE

Model Number	Total Movement(mm)	Joint Opening (mm)		
		Min	Nominal	Max
MSFB25	25	25	25	50
MSFB50	50	25	50	75
MSFB75	77	38	75	115
MSFB100	104	51	100	155
MSFB125	127	64	125	191
MSFB150	153	76	150	229
MSFB175	178	88	175	266
MSFB200	203	102	200	305
MSFB300	305	152	300	457



美硕建材

Nanjing Meishuo Building Materials Co., Ltd
